545/3 CHEMISTRY Paper 3 July - August 2022 2 Hours



## UMTA JOINT MOCK EVAMINATIONS 2022

	U 	MTA JOINT MOCK E	XAMINATIONS – 2022	
1	NDEX NO	SIG	NATURE	Entrana via English
	Ţ	JGANDA CERTIFICA	TE OF EDUCATION	
		CHEMIS	STRY	
		Paper	r 3 · · · · · · · · · · · · · · · · · ·	
		2 Hot	ırs	
INSTRUCTIO				
Answer both q	uestions .Answe owed to use an	ers are to be written in	the spaces provided in th	is book let.
All working m	ust be clearly s	shown.	text books, booklets on q	ualitative analysis etc)
Mathematical ta	bles and silent	non –programmable o	calculators may be used.	
-		For Examiners' Use		]
Q.1			an arra car a recording	The Party Sports of the
Q.2		1 20 11 11 11 11 11 11		

Total

Qn.1 You are provided with the following:

- BAI solution which is a solution of an acid H<sub>n</sub>A, prepared by dissolving 4.9 g of the acid in a litre of distilled water to have a 0.05 M acid solution.
- BA2 solution which is a sodium hydroxide solution containing 2.0 gdm<sup>3</sup> of the base in distilled water.

You are required to carry out the experiment to determine the value of n (the basicity of the acid  $H_nA$ ); and thereafter, the value of A in the acid.

$$(H = 1; O = 16; Na = 23).$$

## Procedure:

- Pipette accurately 25 cm<sup>3</sup> (or 20 cm<sup>3</sup>) of BA2 into a clean conical flask.
- Add 1-2 drops of methyl orange indicator and shake gently.
- Titrate the solution with BA1 from the burette until the solution just changes colour.
- Repeat the titration until you get consistent readings.
- · Record your results in the table below.

(a).	Res	ults:
------	-----	-------

Capacity of pipette used......cm<sup>3</sup>.

Table of results:

Experiment no.	1	2	3
Final burette reading / cm <sup>3</sup>			
Initial burette reading / cm <sup>3</sup>			
Volume of BA1 used / cm <sup>3</sup>			

Titre values used for calculating the average volume of BA1 used:	
ritte values asserver cm <sup>3</sup> .	
Average volume of BA1 used.	
	••••••••
	• • • • • • • • • • • • • • • • • • • •

(b). Calculate the:

Page 2 of 5

(i). number of moles of BA1 that reacted.	in stance in the second of the
(ii) Molarity of BA2 solution.	
(ii) Molarity of 2012	
(II) Mounty	
	ed.
(iii) The number of moles of BA2 that react	
	$t_{\text{mode}}$ with 1 mole of BA1 (= value of $\pi$ ).
(iv) The number of moles of BA2 required	to react with 1 mole of 21-5 (
(v) The value of A in the $H_nA$ acid.	
	•••••
•••••	***************************************

Qn 2. You are provided with substance V which contains one cation and two anions.

You are required to carry out the following tests and identify the cation and anions in V. Identify any gas (es) that may be evolved.

TEST	OBSERVATIONS	DEDUCTIONS
a). Heat a spatula endful of V in a hard dry test tube, first gently and then strongly until there is no further change		
b). Add a spatula endful of V in about 10 cm <sup>3</sup> of distilled water. Shake very well and then filter.		
Keep both the residue and the filtrate.	•	
Divide the filtrate into four portions.		
(i) To first portion in a test tube, add sodium hydroxide solution, drop wise, until in excess.		
(ii) To the second portion, add ammonia solution, drop wise, until in excess.		
(iii) To the third portion, add Lead (II) nitrate solution.		

(iv) Use the forth portion, to carry out a test of your own to confirm the anion in filtrate of V.		
Test:		
(v) Heat some of the residue in a test tube, first gently and then strongly until there is no further change.	-	
(vi) To a part of the remaining residue in a clean test tube, add dilute nitric acid solution		
Identify the:  (i) Cation in V.		
(ii) Anion in the fi	ltrate.	
(iii) The anion in th	e residue.	
	2	