
535/3
Physics Practical
Paper 3
July/Aug 2023
2 1/4 hours



# **KAMSSA JOINT MOCK EXAMINATIONS**

## **Uganda Certificate of Education**

**PHYSICS** 


#### PAPER 3

2hours 15minutes

#### **INSTRUCTIONS TO CANDIDATES:**

- Answer **question 1** and one other question. You will not be allowed to start working with the apparatus for the **first quarter** of an hour.
- Marks are given mainly for a clear record of the observation actually made, for their suitability and accuracy and for the use made of them.
- Candidates are reminded to record their observation as soon as they are made. Whenever possible, candidates should put their observation and calculations in a suitable table drawn in advance.
- An account of the method of carrying out the experiment is not required.
- Squared paper is provided.
- Mathematical tables and silent non programmable calculator may be used

- 1. In this experiment you will determine the acceleration due to gravity, g
- (a). Attach a pointer to one end of the spring provided using a thread.
- (b). Suspend the spring from the free end by tying it on the rod of the retort stand clamp.
- (c). Clamp the half-metre rule vertically as shown in figure below.
- (d). Fix a pointer at the free end of the spring using a little plasticine
- (e). Read and record the position,  $y_0$ , of the pointer against a metre rule



- (f). Suspend a mass M of 0.100kg from the free end of the spring.
- (g). Note the new position, y of the pointer on the meter ruler.
- (h). Calculate the extension d from  $d = (y-y_0)$  in metres,
- (i). Displace the mass, M through a small vertical distance and release it to oscillate.
- (j). Measure and record the time for 20 oscillations.
- (k). Calculate the period, T
- (l). Repeat procedure (f) to (k) above for values of  $M=0.200,0.300,\,0.400,\,0.500$  and 0.600kg.
- (m). Tabulate your values in a suitable table including values of T<sup>2</sup>.
- (n). Plot a graph of T<sup>2</sup> against d
- (0). Find slope, S of your graph.
- (p). Calculate the value of acceleration due to gravity **g** from  $g = \frac{4\pi^2}{s}$ 
  - 2. In this experiment you will be required to determine the focal length, f of the convex lens provided.




Figure 2

- (a). Set up the apparatus as shown below.
- (b). Estimate the focal length,  $f_0$  of the lens by focusing the image of a distant object outside the window on the screen. The image distance of this distant object is equal to the approximate focal length,  $f_0$
- (c). Place an illuminated object at a distance  $u=1.5 f_0$  from the lens.
- (d). Adjust the position of the screen until a sharp image of the wire gauze is obtained on the white screen.
- (e) Measure and record the image distance v.
- (f). Repeat procedures (c) to (e) for object distance u= 2.0 f<sub>0</sub>, 2.5 f<sub>0</sub>, 3.0 f<sub>0</sub> 3.5 f<sub>0</sub> and 4.0 f<sub>0</sub>
- (g). Tabulate your results in a suitable table including values of  $\frac{1}{u}$  and  $\frac{1}{v}$
- (h). Plot a graph of  $\frac{1}{u}$  against  $\frac{1}{v}$
- (i). Find the value of  $y_0$  of  $\frac{1}{u}$  -axis when  $\frac{1}{v} = 0$
- (j). Find the value of  $x_0$  of  $\frac{1}{v}$  -axis when  $\frac{1}{u} = 0$
- (k). Calculate mean focal length of the lens from the expression

$$f = \left(\frac{1}{x_0} + \frac{1}{y_0}\right).$$

3. In this experiment, you will determine the internal resistance, r, of the dry cell provided.

### **PART I**

- (a). Fix the bare wire marked, P on the table using sellotape
- (b). Connect the circuit shown in the figure. with x = 1.000m


Figure 3

Cellotape
Bare wire P

Cellotape

V

- (c). Close switch, K
- (d). Adjust the rheostat so that the ammeter, A, indicates a current I = 0.10 A
- (e). Read and record the voltmeter reading, V<sub>1</sub>
- (f). Calculate the resistance per metre,  $\beta$  of wire P from  $\beta = \frac{V_1}{I x}$



- (a). Connect the circuit as shown in the Figure above
- (b). With the switch, K, open read and record the voltmeter reading, V<sub>0</sub>
- (c). Adjust the length, x to 0.300m
- (d). Close switch K.
- (e). Read and record the ammeter reading, I
- (f). Open switch, K
- (g). Repeat the procedure from (e) to (f) for values of x = 0.400, 0.500, 0.600 and 0.700m
- (h). Tabulate your results including values of  $\frac{V_o}{I}$  and  $\beta x$ .
- (i). Plot a graph of  $\frac{V_o}{I}$  (along the vertical axis) against  $\beta x$  (along the horizontal axis
- (j). Find the intercept, r, on the  $\frac{V_0}{I}$  axis.

**END**